

DESIGNED BY **1/48 HGW WET TRANSFER**
eduard
 MADE IN CZECH REPUBLIC
 PRODUCT CODES: 1x 248074 + 3x 248049
Spitfire Mk.IX
248083

New

Cut out the required design using a sharp scalpel. Soak the base paper in warm water for 20 seconds.
 Remove the transfer from the base paper.
 Apply a layer of Mr. Mark Softener on the surface where you intend to apply the transfer.
 Place the transfer in the required position on the layer of Mr. Mark Softener.
 Carefully press out any excess liquid and bubbles. (Use the cloth and the cotton bud).
 Finally, leave it to dry for 6-8 hours.
 Carefully remove the transparent transfer film.
 Clean off any traces of transfer glue with a wet cloth.

WWW.HGWMODELS.CZ